



PACO KIDS' height chart

Please take the time to measure :

1. Let child against the wall
2. Place a small book between their legs, and make sure the high is comfortable.
3. Measure from the top of the book to the floor.
4. Measure child's arm length and height.
5. From the measure data, we'll recommend a frame that fits child's body shape from different item, this is the safest way to choose a child's bike as most comfortable to ride.



How To Choose A Kid's Bike



Approx age 2~3	Approx age 5~7	Approx age 7~10	Approx age 11~14+
Hight 87~103cm	Hight 100~131cm	Hight 131~150cm	Hight 156cm+
Arm length 43cm↓	Arm length 45~51cm	Arm length 51~56cm	Arm length 60~65cm+
inside leg length 25~31 cm	inside leg length 52~55 cm	inside leg length 55~62 cm	inside leg length 66~75 cm

Suitable models

Balances BIKE Beyond 12" PUSH 12"	ROAD BIKE PR20 PR20 S FLAT ROAD PR20 F CYCLOCROSS CX20 TRACKBIKE PT20	ROAD BIKE PR24 FLAT ROAD PR24 F CYCLOCROSS CX24 TRACKBIKE PT24	ROAD BIKE PR65 FLAT ROAD PR65 F CYCLOCROSS CX65 TRACKBIKE PT65
--	---	---	---

PACO BIKE CO., LTD.
 paco@paco-bike.com
 TEL : +886-4-8384342